



Torque arm installation Guide

1. Install small cog over washer.
2. Test fit the arm.
3. Get the best fit by flipping the small cog over.
4. Add washer to cover cog teeth
5. Put nut back on. Use stainless steel zip ties/hose clamp etc (all found at Home Depot or Harbor freight).

Please Review all the pictures below.









Cog is offset by 1.5 deg. If you do not get a good fit simply flip the cog over







**Put nut back on and install stainless
Zip Ties/Hose Clamp etc
All Found at Home Depot or Harbor Freight**